DETAIL product care and maintenance

O CARIMALI®

RECOMMENDATIONS FOR CORRECT USE

To prevent impurities or debris from reaching the inside of the product and causing operating problems, it is advisable to always purge the system before connecting the supply hoses.

It is also advisable to install a suitable filter at the inlet of the system.

PULIZIA

For the cleaning of metal parts

CHROME VARNISHED WITH GALVANIC TREATMENT PVD IN STAINLESS STEEL

simply use a damp cloth with mild soap diluted with water and rinse. It is recommended that metal surfaces always be wiped dry with a soft, clean cloth to prevent limescale staining.

PLEASE NOTE

It is recommended to use only mild soap-based cleaners diluted with water and soft sponges/cloths.

Never use abrasive cleaners or disinfectants or those containing alcohol, hydrochloric or phosphoric acid, bleach, chlorine or any other acid-containing product.

Do not use sharp objects or hard sponges or scrapers.

AERATORS

To proceed with cleaning the aerators, it will be necessary to remove them from the mixer and soak them in a solution of diluted water and vinegar. It will be necessary to let the aerator soak for a few hours. After this time has elapsed, proceed with a soap and water wash. Finish with a rinse with water only.

This procedure will remove any lime deposits and/or dirt in the filters.

SHOWER HEADS

To prevent limescale from clogging the diffuser, we recommend rubbing the silicone nozzles periodically to rid them of limescale and to keep the diffuser clean at all times.



CALFLEX Srl Zona Industriale 5/bis 28891 Nonio / VB - ITALY Tel. +39 0323 88 93 28 Fax +39 0323 88 93 38 E-mail: info@carimali.it www.carimali.it